


BARACUDA®

THE TRUSTED NAME IN POOL CARE



tracker™

QUICK START GUIDE

1

PREPARING YOUR POOL AND FILTRATION SYSTEM



The filtration system must be operating at its maximum water flow before you install your Tracker, otherwise you will have to read just it after cleaning the pool filter.

Installation is easy if you follow these simple preliminary steps:

1.1 Empty the weir basket

1.2 Clean the pump basket

1.3 Backwash the filter until the sight glass is clear



1.4 Adjust all return jets (whether your pool has one, two or more) to point downwards and towards each other so that you DO NOT see a circular water flow or ripples on the surface of your pool

2

ASSEMBLING YOUR TRACKER

2.1 The Hose Float is already fitted on one of the hoses. Connect this length of hose to the Flow Regulator Valve and twist until it locks into place.

2.2 Connect your cleaner to this length of hose, by pushing the Flow Regulator Valve onto the cleaner swivel. When you hear a click, it is securely connected. Now submerge your cleaner by filling it with water, thereby ensuring all trapped air has escaped. Before connecting to the weir, ensure that all the hoses are filled with water and all the air has been expelled.




3

ASSEMBLING YOUR HOSES

3.1 Always insert the male hose cuff into the female cuff and twist until hose locks together. Hoses must connect fairly tightly. Setting 1 or 2 is recommended on the Twist Lock Ratchet System. The ideal length of hose is from the weir to the farthest point of the pool plus one extra section of hose. If the weir is opposite the steps, use lowest step as furthest point (see Diagram 3). To ensure the best performance from your Tracker, please ensure that only genuine Long-Life Twist Lock Hoses are used.

3.2 Fit the hose float to the first hose section +/- 20 cm from the Tracker head.



3.3 Bleed all the air from the hose by placing one end over the return jet - thus filling the hose length with water.


3.4 Keeping the hose-ends underwater, move the hose from the return line to the weir and connect the male cuff directly to the Auto Weir Valve 90° Elbow.

3.5 Ensure that the Auto Weir Valve is firmly attached to the weir vacuum lid.


4

ADDING HOSE PROTECTOR

4.1 Add your hose protector to the hose which connects to your WEIR (not the pool cleaner). Place the hose in one half of the hose protector. Place other half over hose ensuring male clips line up with the female clips. Apply pressure to both until they lock together.




5 CONNECTING TO WEIR



5.1 Connect the male cuff of the hose to the 90° Twist Lock Elbow. The elbow and Auto Weir Valve connect to the weir as illustrated in the drawing.

Turn the filtration pump on and watch as your pool cleaner begins cleaning.

6 CHECK CLEANER FLOW



6.1 When holding the Tracker™ head under water, watch the yellow wheel marker, use a stopwatch to time 10 wheel rotations.


6.2 Tracker: Wait for wheels to change direction, then begin counting. If the wheel reverses during timing, start over.

IF	Time is ...	Result ...	Adjust Flow ...
	26-50	Poor Performance	Increase Flow +
	20-25		
	10-19	Possible Damage	Decrease Flow -

TROUBLESHOOTING

PROBLEM	SOLUTION
Your BARACUDA Pool Cleaner is performing too fast and/or climbing above the level of the water.	Reduce Auto Weir Valve to medium (2) or low (1) setting.
Your BARACUDA Pool Cleaner is performing slowly and/or not climbing the pool walls.	Increase Auto Weir Valve to medium (2) or high (3) setting.


AUTO WEIR VALVE ADJUSTMENT SETTINGS



REMOVING DEBRIS FROM ENGINE

! To avoid serious injury, make sure that the cleaner is disconnected from the hose and the suction pump is turned off prior to starting this operation.

- 1 Push the yellow release button on the top of the cleaner.
- 2 Lift the top cover back until it clicks into an upward position.
- 3 Look at engine compartment and remove debris that is present.
- 4 If needed, slowly push engine paddles forward and/or backwards to move stuck debris to an accessible position and then remove it. When moving the engine paddles, make sure the cleaner tracks are allowed to move freely as they will turn as the engine paddles rotate.
- 5 Close top cover and ensure it clicks into place.



STANDARD WARRANTY CONDITIONS

WE WARRANT YOUR NEW BARACUDA® POOL CLEANER TO BE FREE FROM MANUFACTURING DEFECTS FOR 2 (TWO) YEARS FROM DATE OF PURCHASE. SUBJECT TO OUR STANDARD WARRANTY CONDITIONS.

The **BARACUDA® TRACKER** warranty excludes:

- damage arising due to abnormal use, lack of care, undue exposure to the elements, chemicals or factors beyond our control.
- any obligation other than the obligation to repair or replace defective parts.
- discolouration (your BARACUDA® Pool Cleaner may become discoloured during normal use but this will in no way affect its operational efficiency).

The BARACUDA® warranty is given in the place of all other warranties and guarantees whether expressed or implied. Warranty claims shall be made at any authorised BARACUDA® dealer in South Africa.

The BARACUDA® warranty applies only within the borders of South Africa and provided that the BARACUDA® Pool Cleaner is used in accordance with instructions packaged with the cleaner.

Warranty only valid if Long-Life Twist Lock hoses are used.

NB: Please keep your proof of purchase as it will be requested upon all warranty claims.



BARACUDA®

Customer Care Telephone: 086 088 7665
customer care@fluidra.co.za

www.baracuda.co.za

Manufactured by: Fluidra Waterlinx (Pty) Ltd
Reg No: 2004/019077/07

5 Kruger Street, Denver, Johannesburg, 2094, South Africa